

# 5 MIPS Assembly Language

- Today, digital computers are almost exclusively programmed using **high-level programming languages** (PLs), *e.g.*, C, C++, Java
- The CPU fetch–execute cycle, however, is *not* prepared to directly execute high-level constructs like *if-then-else*, *do-while*, arithmetic, method invocations, *etc.*
- Instead, a CPU can execute a limited number of rather primitive instructions, its **machine language instruction set**
  - Machine language instructions are encoded as bit patterns which are interpreted during the instruction decode phase
  - A C/C++/Java **compiler** is needed to translate high-level constructs into a series of primitive machine instructions

# Why machine language?

- Even with clever compilers available, machine language level programming is still of importance:
  - machine language programs can be carefully tuned for **speed** (*e.g.*, computationally heavy simulations, controlling graphics hardware)
  - the **size** of machine language programs is usually significantly smaller than the size of high-level PL code
  - specific computer features may only be available at the machine language level (*e.g.*, I/O port access in device drivers)
- For a number of small scale computers (embedded devices, wearable computers)
  - high-level PL compilers are not available yet
  - or high-level PLs are simply not adequate because compilers introduce uncertainty about the time cost of programs (*e.g.*, brake control in a car)

# Machine language vs. assembly language

- *Real* machine language level programming means to handle the bit encodings of machine instructions

**Example** (MIPS CPU: addition  $\$t0 \leftarrow \$t0 + \$t1$ ):

10000100101000000000100000

- **Assembly language** introduces symbolic names (**mnemonics**) for machine instructions and makes programming less error-prone:

**Example** (MIPS CPU: addition  $\$t0 \leftarrow \$t0 + \$t1$ ):

add \$t0, \$t0, \$t1

- An **assembler** translates mnemonics into machine instructions
  - Normally: mnemonic  $\xleftrightarrow{1:1}$  machine instruction
  - Also: the assembler supports **pseudo instructions** which are translated into series of machine instructions (mnemonic  $\xleftrightarrow{1:n}$  machine instruction)

# The MIPS R2000/R3000 CPU

- Here we will use the MIPS CPU family to explore assembly programming
  - MIPS CPU originated from research project at Stanford, most successful and flexible CPU design of the 1990s
  - MIPS CPUs were found in SGI graphics workstations, Windows CE handhelds, CISCO routers, and Nintendo 64 video game consoles
- MIPS CPUs follow the RISC (**R**educed **I**nstruction **S**et **C**omputer) design principle:
  - limited repertoire of machine instructions
  - limited arithmetical complexity supported
  - extensive supply of CPU registers (reduce memory accesses)
- Here: work with MIPS R2000 instruction set (use MIPS R2000 simulator SPIM: <http://www.cs.wisc.edu/~larius/spim.html>)


# MIPS: memory layout

- The MIPS CPU is a 32-bit architecture (all registers are 32 bits wide)
  - Accessible memory range: 0x00000000–0xFFFFFFFF
- MIPS is a von-Neumann computer: memory holds both instructions (*text*) and *data*.
  - Specific memory **segments** are coventionally used to tell instructions from data:

Address	Segment
0x7FFFFFFF	stack
↓	↓
↑	↑
0x10000000	data
0x00400000	text
0x00000000	reserved

- If a program is loaded into SPIM, its `.text` segment is automatically placed at 0x00400000, its `.data` segment at 0x10000000

# MIPS: 32-bit, little endian

- A MIPS **word** has 32 bits (a **halfword** 16 bits, a **byte** 8 bits)
- The MIPS architecture is **little-endian**: in memory, a word (halfword) is stored with its *least significant byte first* 
- **Example** (representation of 32-bit word 0x11223344 at address  $n$ ):

Address	$n$	$n + 1$	$n + 2$	$n + 3$
Value	0x44	0x33	0x22	0x11

(Intel Pentium: big-endian)

- MIPS requires words (and halfwords) to be stored at **aligned addresses**:
  - if an object is of size  $s$  bytes, its storage address needs to be divisible by  $s$  (otherwise: CPU halts with *address error exception*)

# MIPS: registers

- MIPS comes with 32 **general purpose registers** named \$0...\$31  
Registers also have symbolic names reflecting their conventional<sup>8</sup> use:

Register	Alias	Usage	Register	Alias	Usage
\$0	\$zero	constant 0	\$16	\$s0	saved temporary
\$1	\$at	used by assembler	\$17	\$s1	saved temporary
\$2	\$v0	function result	\$18	\$s2	saved temporary
\$3	\$v1	function result	\$19	\$s3	saved temporary
\$4	\$a0	argument 1	\$20	\$s4	saved temporary
\$5	\$a1	argument 2	\$21	\$s5	saved temporary
\$6	\$a2	argument 3	\$22	\$s6	saved temporary
\$7	\$a3	argument 4	\$23	\$s7	saved temporary
\$8	\$t0	unsaved temporary	\$24	\$t8	unsaved temporary
\$9	\$t1	unsaved temporary	\$25	\$t9	unsaved temporary
\$10	\$t2	unsaved temporary	\$26	\$k0	reserved for OS kernel
\$11	\$t3	unsaved temporary	\$27	\$k1	reserved for OS kernel
\$12	\$t4	unsaved temporary	\$28	\$gp	pointer to global data
\$13	\$t5	unsaved temporary	\$29	\$sp	stack pointer
\$14	\$t6	unsaved temporary	\$30	\$fp	frame pointer
\$15	\$t7	unsaved temporary	\$31	\$ra	return address

<sup>8</sup>Most of these conventions concern procedure call and return (library interoperability)

# MIPS: load and store

- Typical for the RISC design, MIPS is a **load-store architecture**:
  - Memory is accessed *only* by explicit *load* and *store* instructions
  - Computation (e.g., arithmetics) reads operands from registers and writes results back into registers
- MIPS: **load** word/halfword/byte at address  $a$  into target register  $r$  ( $r \leftarrow (a)$ ):

Instruction	Remark	Pseudo?
<code>lw <math>r, a</math></code>		
<code>lh <math>r, a</math></code>	sign extension	
<code>lb <math>r, a</math></code>	sign extension	
<code>lhu <math>r, a</math></code>	no sign extension	
<code>lbu <math>r, a</math></code>	no sign extension	



# MIPS: load and store

- **Example** (load word/halfword/byte into temporary registers):

```

        .text
        .globl  __start
__start:
        # load with sign extension
        lw      $t0, memory
        lh      $t1, memory
        lb      $t2, memory
        # load without sign extension
        lhu     $t3, memory
        lbu     $t4, memory

        .data
memory:
        .word   0xABCDE080      # little endian: 80E0CDAB

```

Register	Value
\$t0	0xABCDE080
\$t1	0xFFFFE080
\$t2	0xFFFFFFFF80
\$t3	0x0000E080
\$t4	0x00000080

# MIPS: load and store

- MIPS: **store** word/halfword/byte in register  $r$  at address  $a$  ( $a \leftarrow r$ ):

Instruction	Remark	Pseudo?
<code>sw <math>r, a</math></code>		
<code>sh <math>r, a</math></code>	stores low halfword	
<code>sb <math>r, a</math></code>	stores low byte	

**Example** (swap values in registers  $\$t0$  and  $\$t1$ ):

```

.text
.globl __start
__start:
# swap values $t0 and $t1 ... slow!
sw    $t0, x
sw    $t1, y
lw    $t0, y
lw    $t1, x

.data
x:
.word 0x000000FF
y:
.word 0xABCDE080

```

# MIPS: move


- MIPS can **move** data between registers directly (no memory access involved)

Instruction	Remark	Pseudo?
move $r, s$	target $r$ , source $s$ ( $r \leftarrow s$ )	×

**Example** (swap values in registers \$t0 and \$t1, destroys \$t2):

```
.text
.globl __start
__start:
# swap values $t0 and $t1 (clobbers $t2)
move    $t2, $t0
move    $t0, $t1
move    $t1, $t2

# no .data segment
```

- By convention, destroying the contents of the \$t $n$  registers is OK (\$s $n$  registers are assumed intact once a procedure returns )

# MIPS: logical instructions

- MIPS CPUs provide instructions to compute common boolean functions

Instruction	Remark	Pseudo?
<code>and r, s, t</code>	$r \leftarrow s \cdot t$	
<code>andi r, s, c</code>	$r \leftarrow s \cdot c$ ( $c$ constant)	
<code>or r, s, t</code>	$r \leftarrow s + t$	
<code>ori r, s, c</code>	$r \leftarrow s + c$ ( $c$ constant)	
<code>nor r, s, t</code>	$r \leftarrow \overline{s + t}$	
<code>xor r, s, t</code>	$r \leftarrow s \text{ XOR } t$	
<code>xori r, s, c</code>	$r \leftarrow s \text{ XOR } c$ ( $c$ constant)	
<code>not r, s</code>	$r \leftarrow \bar{s}$	×

- The `andi`, `ori`, `xori` instructions use **immediate addressing**: the constant  $c$  is encoded in the instruction bit pattern

**Example** (bit pattern for instruction `andi $x, $y, c` with  $0 \leq x, y \leq 31$ ):


$\underbrace{001100}_{\text{andi}} \underbrace{bbbb}_{y} \underbrace{bbbb}_{x} \underbrace{bbbbbbbbbbbbbbbb}_{c \text{ (16 bit)}}$

# MIPS: pseudo instructions

- The MIPS standard defines the CPU instruction set as well as **pseudo instructions**
- The assembler translates pseudo instructions into real MIPS instructions

**Example** (translation of pseudo instructions):

Pseudo instruction	MIPS instruction	Remark
<code>not r, s</code>	<code>nor r, s, \$0</code>	
<code>move r, s</code>	<code>or r, s, \$0</code>	
<code>li r, c</code>	<code>ori r, \$0, c</code>	load immediate ( <i>c</i> : 16 bit constant)

- How does the assembler translate `li r, 0xABCDEF00` (*c* in `ori` is 16 bit only)? 

Pseudo instruction	MIPS instructions <sup>9</sup>	Remark
<code>li r, 0xABCDEF00</code>	<code>lui \$at, 0xABCD</code> <code>ori r, \$at, 0xEF00</code>	( <i>c</i> : 32 bit constant)

<sup>9</sup>MIPS instruction: `lui r, c`: load constant halfword *c* into upper halfword of register *r*

# MIPS: using pseudo instructions

- **Example** (replace the low byte of \$t0 by the low byte of \$t1, leaving \$t0 otherwise intact—use **bitmasks** and logical instructions):

```

        .text
        .globl  __start
__start:
        li      $t0, 0x11223344
        li      $t1, 0x88776655
        # paste the low byte of $t1 into the low byte of $t0
        # ($t0 = 0x11223355)
        and     $t0, $t0, 0xFFFFFFFF00  # pseudo
        and     $t1, $t1, 0xFF          # assembler translates -> andi
        or      $t0, $t0, $t1

        # no .data segment

```

- Expand the pseudo instruction:

Pseudo instruction	MIPS instructions
and \$t0, \$t0, 0xFFFFFFFF00	lui \$at, 0xFFFF ori \$at, 0xFF00 and \$t0, \$t0, \$at

# MIPS: optimized register swap

- **Question:** swap the contents of register \$t0 and \$t1 without using memory accesses and without using temporary registers)

```
.text
.globl __start
__start:
# swap values of $t0 and $t1 (xor-based)
xor    $t0, $t0, $t1
xor    $t1, $t0, $t1
xor    $t0, $t0, $t1

# no .data segment
```

- Explain how this “*xor swap*” works!

## Remember:

- ①  $a \text{ XOR } 0 = a$
- ②  $a \text{ XOR } a = 0$

# MIPS: arithmetic instructions

- MIPS provides unsigned and signed (two's complement) 32-bit integer arithmetics

Instruction	Remark	Pseudo?
<code>add r, s, t</code>	$r \leftarrow s + t$	
<code>addu r, s, t</code>	without overflow	
<code>addi r, s, c</code>	$r \leftarrow s + c$	
<code>addiu r, s, c</code>	without overflow	
<code>sub r, s, t</code>	$r \leftarrow s - t$	
<code>subu r, s, t</code>	without overflow	
<code>mulo r, s, t</code>	$r \leftarrow s \times t$	×
<code>mul r, s, t</code>	without overflow	×
<code>div r, s, t</code>	$r \leftarrow s/t$	×
<code>divu r, s, t</code>	without overflow	×

- The 64-bit result of `mulo` (`mul`) is stored in the special registers `$hi` and `$lo`; `$lo` is moved into  $r$ <sup>10</sup>
- `div` (`divu`): MIPS places the quotient in `$lo`, remainder in `$hi`; `$lo` is moved into  $r$

<sup>10</sup>Access to `$lo`, `$hi`: `mflo`, `mfhi` (read) and `mtlo`, `mthi` (write)



# MIPS: arithmetic and shift/rotate instructions

Instruction	Remark	Pseudo?
abs $r, s$	$r \leftarrow  s $	×
neg $r, s$	$r \leftarrow -s$	×
negu $r, s$	without overflow	×
rem $r, s, t$	$r \leftarrow$ remainder of $s/t$	×
remu $r, s, t$	without overflow	×
sll $r, s, c$	$r \leftarrow$ shift $s$ left $c$ bits, $r_{0\dots c-1} \leftarrow 0$	
sllv $r, s, t$	$r \leftarrow$ shift $s$ left $t$ bits, $r_{0\dots t-1} \leftarrow 0$	
srl $r, s, c$	$r \leftarrow$ shift $s$ right $c$ bits, $r_{31-c+1\dots 31} \leftarrow 0$	
srlv $r, s, t$	$r \leftarrow$ shift $s$ right $t$ bits, $r_{31-t+1\dots 31} \leftarrow 0$	
sra $r, s, c$	$r \leftarrow$ shift $s$ right $c$ bits, $r_{31-c+1\dots 31} \leftarrow s_{31}$	
srav $r, s, t$	$r \leftarrow$ shift $s$ right $t$ bits, $r_{31-t+1\dots 31} \leftarrow s_{31}$	
rol $r, s, t$	$r \leftarrow$ rotate $s$ left $t$ bits	×
ror $r, s, t$	$r \leftarrow$ rotate $s$ right $t$ bits	×

- **Question:** How could the assembler implement the rol, ror pseudo instructions?

# MIPS: shift/rotate instructions

- MIPS assemblers implement the pseudo rotation instructions (`rol`, `ror`) based on the CPU shifting instructions:

<pre> .text .globl __start __start: # rotate left 1 bit li    \$t0, 0x80010004 rol   \$t1, \$t0, 1  # rotate right 3 bits li    \$t0, 0x80010004 ror   \$t1, \$t0, 3  # no .data segment </pre>	<p>→</p>	<pre> .text .globl __start __start: # rotate left 1 bit lui   \$at, 0x8001 ori   \$t0, \$at, 0x0004 srl   \$at, \$t0, 31 sll   \$t1, \$t0, 1 or    \$t1, \$t1, \$at  # rotate right 3 bits lui   \$at, 0x8001 ori   \$t0, \$at, 0x004 sll   \$at, \$t0, 29 srl   \$t1, \$t0, 3 or    \$t1, \$t1, \$at  # no .data segment </pre>
---	----------	--


# MIPS: branch instructions

- **Branch instructions** provide means to change the program control flow (manipulate the CPU IP register)
  - The CPU can branch unconditionally (**jump**) or depending on a specified condition (e.g., equality of two registers, register  $\leq 0$ , ...)
  - In assembly programs, the branch target may be specified via a **label**—internally the branch instruction stores an 16-bit **offset**

```

      :
again: lw   $t0, memory
       sub  $t0, $t0, 1
       beqz $t0, exit      # jump offset: 2 instructions
       b    $t0, again     # jump offset: -4 instructions
exit:  sw   $t1, memory
      :

```



- With a 16-bit offset, MIPS can branch  $2^{15} - 1$  ( $2^{15}$ ) instructions backward (forward)

# MIPS: branch instructions

Instruction	Condition	Remark	Pseudo?	MIPS instructions
b <i>l</i>	none	$IP \leftarrow l$	×	beq \$zero, \$zero, <i>l</i>
beq <i>r, s, l</i>	$r = s$			
bne <i>r, s, l</i>	$r \neq s$			
bgez <i>r, l</i>	$r \geq 0$			
bgtz <i>r, l</i>	$r > 0$			
blez <i>r, l</i>	$r \leq 0$			
bltz <i>r, l</i>	$r < 0$			
beqz <i>r, l</i>	$r = 0$		×	beq <i>r</i> , \$zero, <i>l</i>
bnez <i>r, l</i>	$r \neq 0$		×	bne <i>r</i> , \$zero, <i>l</i>
bge <i>r, s, l</i>	$r \geq s$		×	slt \$at, <i>r</i> , <i>s</i> <sup>11</sup> beq \$at, \$zero, <i>l</i>
bgt <i>r, s, l</i>	$r > s$		×	slt \$at, <i>s</i> , <i>r</i> bne \$at, \$zero, <i>l</i>
ble <i>r, s, l</i>	$r \leq s$		×	slt \$at, <i>s</i> , <i>r</i> beq \$at, \$zero, <i>l</i>
blt <i>r, s, l</i>	$r < s$		×	slt \$at, <i>r</i> , <i>s</i> bne \$at, \$zero, <i>l</i>

<sup>11</sup>slt \$at, *r*, *s*: \$at ← 1 if  $r < s$ , \$at ← 0 otherwise.

# MIPS: comparison instructions

- Compare the values of two registers (or one register and a constant)

– Comparison  $\begin{cases} \text{successful: } r \leftarrow 1 \\ \text{fails: } r \leftarrow 0 \end{cases}$

Instruction	Comparison	Remark	Pseudo?	MIPS instructions
<code>slt r, s, t</code>	$s < t$			
<code>sltu r, s, t</code>	$s < t$	unsigned		
<code>slti r, s, c</code>	$s < c$	c 16-bit constant		
<code>sltiu r, s, c</code>	$s < c$	unsigned		
<code>seq r, s, t</code>	$s = t$		×	<code>beq s, t, 3</code> <code>ori r, \$zero, 0</code> <code>beq \$zero, \$zero, 2</code> <code>ori r, \$zero, 1</code>
<code>sne r, s, t</code>	$s \neq t$		×	
<code>sge r, s, t</code>	$s \geq t$		×	
<code>sgeu r, s, t</code>	$s \geq t$	unsigned	×	
<code>sgt r, s, t</code>	$s > t$		×	
<code>sgtu r, s, t</code>	$s > t$	unsigned	×	
<code>sle r, s, t</code>	$s \leq t$		×	
<code>sleu r, s, t</code>	$s \leq t$	unsigned	×	

# MIPS: division by zero, overflow

- Arithmetic exceptions (division by 0, overflow during multiplication) are handled on the MIPS instruction layer itself:

– MIPS instructions for `div $t0, $t1, $t2`:

```
bne    $t2, $zero, 2
break  $0                # exception: division by 0
div    $t1, $t2          # quotient in $lo, remainder in $hi
mflo   $t0
```

– MIPS instructions for `mulo $t0, $t1, $t2`:

```
mult   $t1, $t2          # result bits 31..0 in $lo, 63..32 in $hi
mfhi   $at
mflo   $t0
sra    $t0, $t0, 31     # $t0 = 0x00000000 or 0xFFFFFFFF (sign bit)
beq    $at, $t0, 2
break  $0                # exception: arithmetic overflow
mflo   $t0
```

# Compute Fibonacci numbers (iteratively)

- The **Fibonacci numbers**<sup>12</sup> are an infinite sequence of positive integers (originally used to describe the development of rabbit populations)
  - Start of sequence:  
0, 1, 1, 2, 3, 5, 8, 13, 21, 34, 55, 89, 144, 233, 377, 610, 987, . . .
  - The  $n$ -th Fibonacci number is **recursively defined** as follows:

$$fib(n) = \begin{cases} 0 & \text{if } n = 0 \\ 1 & \text{if } n = 1 \\ fib(n - 2) + fib(n - 1) & \text{if } n \geq 2 \end{cases}$$

**Example** (compute  $fib(3)$ ):

$$fib(3) = fib(1) + fib(2) = 1 + fib(0) + fib(1) = 1 + 0 + 1 = 2$$

---

<sup>12</sup>Leonardo Fibonacci (Leonardo di Pisa), 1200

# Compute Fibonacci numbers (iteratively)

Register	Usage
\$a0	parameter $n$
\$v0	last Fibonacci number computed so far (and result)
\$t0	second last Fibonacci number computed so far
\$t1	temporary scratch register

```

        .text
        .globl __start
__start:
        li      $a0, 1                # fib(n): parameter n

        move    $v0, $a0              # n < 2 => fib(n) = n
        blt     $a0, 2, done
        li      $t0, 0                # second last Fib' number
        li      $v0, 1                # last Fib' number
fib:     add     $t1, $t0, $v0         # compute next Fib' number in sequence
        move    $t0, $v0              # update second last
        move    $v0, $t1              # update last
        sub     $a0, $a0, 1           # more work to do?
        bgt     $a0, 1, fib           # yes: iterate again
done:    sw     $v0, result           # no: store result, done


        .data
result:  .word  0x11111111

```



# MIPS: Booth's algorithm

- Remember Booth's algorithm to multiply two's complement numbers
  - Note: equivalent functionality is provided by MIPS instruction `mult`



- Register assignment:

Register	Usage
\$a0	A
\$a1	C
\$v0	R
\$t0	i
\$t1	A <sub>-1</sub> (only bit 0 of \$t1 used)

- Implementation quite straightforward, ASR of “connected registers” R, A, A<sub>-1</sub> needs some care

# MIPS: Booth's algorithm

```

        .text
        .globl  __start
__start:
        li      $a0, -5           # parameter A
        li      $a1, 7           # parameter C

        li      $v0, 0           # R ← 0
        li      $t1, 0           # A(-1) ← 0
        li      $t0, 32          # i ← n (32 bits)

booth:
        and     $t2, $a0, 0x00000001 # $t2 ← A0
        sll    $t2, $t2, 1
        or     $t2, $t2, $t1       # $t2 = A0, A(-1)

        beq    $t2, 2, case10     # $t2 = 10?
        beq    $t2, 1, case01     # $t2 = 01?
        b      shift              # $t2 = 00 or $t2 = 11
case10: sub    $v0, $v0, $a1       # R ← R - C
        b      shift
case01: add    $v0, $v0, $a1       # R ← R + C
shift:
        and    $t1, $a0, 0x00000001 # A(-1) ← A0
        and    $t2, $v0, 0x00000001 # save R0
        sll    $t2, $t2, 31
        srl    $a0, $a0, 1         # shift right A
        or     $a0, $a0, $t2       # A31 ← R0
        sra    $v0, $v0, 1         # arithmetic shift right R

        sub    $t0, $t0, 1         # i ← i - 1
        bnez   $t0, booth          # i = 0?
        # result in $v0, $a0

```

# MIPS: Addressing modes

- A MIPS instruction like

```
lb $t0, memory
```

addresses a given, *fixed* address in memory.

- Commonly, however, programs need to **access consecutive ranges of memory addresses** (*e.g.*, to perform **string processing**)

**Example** (place string representation in the data segment):

```
.data
```

```
str:    .asciiz "foobar"    # null-terminated ASCII encoded string
```

Content of data segment at address `str`:

Address	<code>str+0</code>	<code>str+1</code>	<code>str+2</code>	<code>str+3</code>	<code>str+4</code>	<code>str+5</code>	<code>str+6</code>
Value	102	111	111	98	97	114	0

# MIPS: Addressing modes

- **Assembler instructions** available to place constant sequences of data into data segment:

Assembler instruction	Data
<code>.ascii s</code>	ASCII encoded characters of string $s$
<code>.asciiz s</code>	like <code>.ascii</code> , null-terminated
<code>.word <math>w_1, w_2, \dots</math></code>	32-bit words $w_1, w_2, \dots$
<code>.half <math>h_1, h_2, \dots</math></code>	16-bit halfwords $h_1, h_2, \dots$
<code>.byte <math>b_1, b_2, \dots</math></code>	8-bit bytes $b_1, b_2, \dots$
<code>.float <math>f_1, f_2, \dots</math></code>	32-bit single precision floating point numbers $f_1, f_2, \dots$
<code>.double <math>d_1, d_2, \dots</math></code>	64-bit double precision floating point numbers $d_1, d_2, \dots$
<code>.space <math>n</math></code>	$n$ zero bytes

- To consecutively access all characters (bytes, halfwords, words) in such a sequence, the CPU needs to **compute the next address** to access

# MIPS: Indirect addressing

- **Indirect Addressing:** address is held in a register

## Example:

```

.text

la    $t0, str
lb    $t1, ($t0)    # access byte at address $t0 ('f')
add   $t0, $t0, 3
lb    $t2, ($t0)    # access byte at address $t0 + 3 ('b')

.data

str:  .asciiz "foobar"

```

-  Note the difference between

`lw $t0, a`      and      `la $t0, a`

# MIPS: Indexed addressing

- Actually, in keeping with the RISC philosophy, MIPS has only one general memory addressing mode: **indexed addressing**
  - In indexed addressing, addresses are of the form (16-bit constant  $c$ , CPU register  $r$ )

$$c(r)$$

- $r$  holds a 32-bit address to which the signed 16-bit constant  $c$  is *added* to form the final address

**Example** (repeated from last slide):

```
.text
```

```
la      $t0, str
```

```
lb      $t1, 0($t0)    # access byte at address $t0 ('f')
```

```
lb      $t2, 3($t0)    # access byte at address $t0 + 3 ('b')
```

```
.data
```

```
str:   .asciiz "foobar"
```

# MIPS: Indexed addressing

- **Example** (copy a sequence of  $n$  bytes from address `src` to address `dst`):

```

        .text
        .globl  __start
__start:
        # length n of byte sequence - 1
        li     $t0, 5
copy:
        lb     $t1, src($t0)    # pseudo! (src: 32 bits wide)
        sb     $t1, dst($t0)
        sub    $t0, $t0, 1
        bgez   $t0, copy

        .data

src:    .byte 0x11, 0x22, 0x33, 0x44, 0x55, 0x66
dst:    .space 6

```

- **Questions:** which changes are necessary to turn this into a  $n$  word ( $n$  halfword) copy routine?

# MIPS: Optimized copy routine

- Copying byte sequences via `lb/sb` is inefficient on von-Neumann machines

```

        .text
        .globl  __start
__start:
        li      $a0, 11           # length n of byte sequence
        la     $a1, src          # source address
        la     $a2, dst          # destination address

        and    $t1, $a0, 0x03
        srl   $t0, $a0, 2
copy:   beqz   $t0, rest
        lw    $t2, ($a1)
        sw    $t2, ($a2)
        add  $a1, $a1, 4
        add  $a2, $a2, 4
        sub  $t0, $t0, 1
        b    copy
rest:   beqz   $t1, done
        lb   $t2, ($a1)
        sb   $t2, ($a2)
        add  $a1, $a1, 1
        add  $a2, $a2, 1
        sub  $t1, $t1, 1
        b    rest
done:

        .data

        .align 4
src:    .byte 0x00, 0x11, 0x22, 0x33, 0x44, 0x55, 0x66, 0x77, 0x88, 0x99, 0xAA
        .align 4
dst:    .space 11

```



# MIPS: Addressing modes (summary)

Mode	Example	MIPS instruction(s)	Remark [Address]
immediate	<code>andi \$t0, \$t0, 0x03</code>		16-bit constant embedded in instruction
IP relative	<code>beqz \$t0, done</code>		signed 16-bit jump offset $o$ embedded in instruction [IP + 4 × $o$ ]
direct	<code>lw \$t0, 0x11223344</code>	<code>lui \$at, 0x1122</code> <code>lw \$t0, 0x3344(\$at)</code>	[0x11223344]
indirect	<code>lw \$t0, (\$t1)</code>	<code>lw \$t0, 0(\$t1)</code>	[\$t1]
indexed	<code>lw \$t0, 0x11223344(\$t1)</code>	<code>lui \$at, 0x1122</code> <code>addu \$at, \$at, \$t1</code> <code>lw \$t0, 0x3344(\$at)</code>	[0x11223344 + \$t1]

# SPIM: System calls

- The MIPS emulator SPIM provides a few services (**system calls**) which would normally be provided by the underlying **operating system**
  - Most importantly, these services provide basic console input/output (I/O) functionality to read/write numbers and strings

Service	Call code	Arguments	Result
print integer	1	\$a0: integer	
print null-term. string	4	\$a0: string address	
read integer	5		\$v0: integer
read string	8	\$a0: buffer address, \$a1: length	
exit	10		

## Remarks:

- Place system call code in \$v0, then execute `syscall`
- System call *read integer* reads an entire line (including newline) and ignores characters following the number
- The *read string* system call reads at most \$a1 – 1 characters into the buffer and terminates the input with a null byte

# SPIM: System calls

- **Example** (read integer  $n$  from SPIM console, then print  $42 \times n$  on console):

```
        .text
        .globl  __start
__start:
        li      $v0, 5                # read integer
        syscall
        mul     $t0, $v0, 42          # compute and save result

        li      $v0, 4                # print string
        la      $a0, the_result_is
        syscall

        li      $v0, 1                # print integer
        move    $a0, $t0
        syscall

        li      $v0, 10               # exit
        syscall

        .data

the_result_is:
        .asciiz "The result is "
```

# SPIM: System calls

- **Example** (read integer  $n$ , then print hexadecimal equivalent on console):
  - **Idea:** groups of 4 bits correspond to one hexadecimal digit (0...F), use value of group (0...15) as index into table of hexadecimal digits

```

        .text
        .globl  __start
__start:
        li      $v0, 5                # read integer n
        syscall
        move   $t0, $v0              # save n

        li      $t1, 7                # 7 (+ 1) hex digits for 32 bits
hexify: and     $t2, $t0, 0x0F         # extract least significant 4 bits
        srl    $t0, $t0, 4            # prepare for next digit
        lb     $t3, hex_table($t2)    # convert 4 bit group to hex digit
        sb     $t3, hex_digits($t1)   # store hex digit
        sub    $t1, $t1, 1            # next digit
        bgez   $t1, hexify            # more digits?

        li      $v0, 4                # print string
        la     $a0, the_result_is
        syscall
        li      $v0, 10               # exit
        syscall

        .data

hex_table: .ascii "0123456789ABCDEF"
the_result_is: .ascii "Hexadecimal value: 0x"
hex_digits: .ascii "XXXXXXXX"

```

# Bubble sort

- **Bubble sort** is a simple sorting algorithm (with *quadratic complexity*: to sort  $n$  items, bubble sort in general needs  $n^2$  steps to complete)

- **Input:** array  $A$  of  $n$  items (numbers, strings, ...) and an ordering  $<$ , e.g.,  $n = 5$ :

$A[0]$	$A[1]$	$A[2]$	$A[3]$	$A[4]$
3	4	10	5	3

- **Output:** sorted array  $A$ , e.g.:

$A[0]$	$A[1]$	$A[2]$	$A[3]$	$A[4]$
3	3	4	5	10

- **Basic idea:**

- ①  $j \leftarrow n - 1$  (index of last element in  $A$ )
- ② If  $A[j] < A[j - 1]$ , swap both elements
- ③  $j \leftarrow j - 1$ , goto ② if  $j > 0$
- ④ Goto ① if a swap occurred

# Bubble sort (trace)

①

A[0]	A[1]	A[2]	A[3]	A[4]
3	4	10	5	③

②

A[0]	A[1]	A[2]	A[3]	A[4]
3	4	10	③ ↔ 5	

③

A[0]	A[1]	A[2]	A[3]	A[4]
3	4	10	③	5

②

A[0]	A[1]	A[2]	A[3]	A[4]
3	4	③ ↔ 10		5

③

A[0]	A[1]	A[2]	A[3]	A[4]
3	4	③	10	5

②

A[0]	A[1]	A[2]	A[3]	A[4]
3	③ ↔ 4		10	5

③

A[0]	A[1]	A[2]	A[3]	A[4]
3	③	4	10	5

②

A[0]	A[1]	A[2]	A[3]	A[4]
③ ↔ 3		4	10	5

④ Swap occurred? (Yes, goto ①)

①

A[0]	A[1]	A[2]	A[3]	A[4]
3	3	4	10	⑤

# MIPS: Bubble sort

```

        .text
        .globl  __start
__start:
        li      $a0, 10                # parameter n

        sll     $a0, $a0, 2            # number of bytes in array A
outer:
        sub     $t0, $a0, 8            # $t0: j-1
        li     $t1, 0                  # no swap yet
inner:
        lw     $t2, A+4($t0)           # $t2 <- A[j]
        lw     $t3, A($t0)             # $t3 <- A[j-1]
        bgt    $t2, $t3, no_swap       # A[j] <= A[j-1]?

        sw     $t2, A($t0)             # A[j-1] <- $t2 \ move bubble
        sw     $t3, A+4($t0)           # A[j] <- $t3 / $t2 upwards
        li     $t1, 1                  # swap occurred
no_swap:
        sub     $t0, $t0, 4            # next array element
        bgez   $t0, inner              # more?

        bnez   $t1, outer              # did we swap?

        li     $v0, 10                 # exit
        syscall

        .data

A:
        .word  4,5,6,7,8,9,10,2,1,3   # array A (sorted in-place)

```

# Procedures (sub-routines)

- The solution to a complex programming problem is almost always assembled from simple program pieces (**procedures**) which constitute a small building block of a larger solution
- Often, procedures provide some service which can then be requested by the **main program** in *many places*
  - Instead of copying and repeating the procedure code over and over,
    - ① the main program **calls** the procedure  
(jumps to the procedure code),
    - ② the called procedure does its job before it **returns** control  
(jumps back to the instruction *just after* the procedure call)
  - The main program is often referred to as the **caller**, the procedure as the **callee**



# MIPS: Procedure example


- **Example** (procedure to compute the average of two parameters  $x, y$ ):
  - Input: parameter  $x$  in  $\$a0$ , parameter  $y$  in  $\$a1$
  - Output: average of  $x, y$  in  $\$v0$   $\left( \$v0 \leftarrow \frac{\$a0 + \$a1}{2} \right)$

```

.text

# procedure average (x,y)
#   input:  x in $a0, y in $a1
#   output: $v0

average:
    add    $v0, $a0, $a1    # $v0 <- $a0 + $a1
    sra   $v0, $v0, 1      # $v0 <- $v0 / 2

    j     ???              #  where to return to?

```

# MIPS: Procedure call

- A typical main program (caller of average) might look like as follows:

```

        .text

        :
        li    $a0, $t0        # set parameter x
        li    $a1, 12        # set parameter y
        j     average        # compute average
★1:    move   $t0, $v0        # save result
        :

        :
        li    $a0, $t0        # set parameter x
        li    $a1, $t1        # set parameter y
        j     average        # compute average
★2:    move   $t1, $v0        # save result
        :

```

- After the first call, average needs to return to label ★1, after the second call the correct address to return to is ★2

# MIPS: Procedure call and return

- MIPS instruction `jal` (*jump and link*) jumps to the given address  $a$  (procedure entry point) and records the correct **return address** in register `$ra`:

Instruction	Effect
<code>jal a</code>	$\$ra \leftarrow IP + 4$ $IP \leftarrow a$

- The callee may then simply return to the correct address in the caller via

Instruction	Effect
<code>j \$ra</code>	$IP \leftarrow \$ra$

- `$ra` is reserved MIPS CPU register \$31; programs overwriting/abusing `$ra` are likely to yield chaos

# MIPS: Procedure call and return<sup>13</sup>

```

.text

:
li      $a0, $t0      # set parameter x
li      $a1, 12       # set parameter y
jal     average       # compute average ($ra = ★1)
★1:    move     $t0, $v0 # save result
:
li      $a0, $t0      # set parameter x
li      $a1, $t1      # set parameter y
jal     average       # compute average ($ra = ★2)
★2:    move     $t1, $v0 # save result
:
li      $v0, 10       # exit program
syscall

# procedure average (x,y)
#  input:  x in $a0, y in $a1
#  output: $v0

average:
add     $v0, $a0, $a1  # $v0 <- $a0 + $a1
sra     $v0, $v0, 1    # $v0 <- $v0 / 2
j       $ra           # return to caller

```

<sup>13</sup>NB: The ★ labels merely illustrate the effect of jal and do not appear in the real assembly file

# Recursive algorithms/procedures

- Some algorithms solve a complex problem as follows:
  - ① Is the size of the problem such that we can trivially solve it?  
Yes  $\Rightarrow$  Return the answer immediately
  - ② Try to reduce the size/complexity of the original problem
  - ③ **Invoke the algorithm** on the reduced problem
- In step ③, the algorithm *invokes itself* to compute the answer; such algorithms are known as **recursive**
- Recursion may also be used in MIPS assembly procedures, typically:

```
        .text
        :
proc:   ...           # code for procedure proc
        :
        jal proc     # recursive call
        :
```

# Binary search

- **Binary search** is a recursive algorithm that searches for a given value (*needle*) in a *sorted array* of values
- General idea:
  - ① If the array is of size 1 only, compare *needle* against the array entry, return result of comparison (*true/false*)
  - ② Locate the middle array entry  $m$ ; compare *needle* and  $m$
  - ③ – If  $needle = m$  return *true*
    - If  $needle < m$ , **call binary search** on left half of array
    - Otherwise, **call binary search** on right half of array
- NB: since the array is sorted, we know for all entries  $a$  to the left of  $m$  that  $a \leq m$  (for all entries  $b$  to the right of  $m$ :  $b \geq m$ )

# Binary search (example, needle = 35)

①	A[0]	A[1]	A[2]	A[3]	A[4]	A[5]	A[6]	A[7]	A[8]	A[9]
	2	3	8	10	16	21	35	42	43	50
②	A[0]	A[1]	A[2]	A[3]	A[4]	A[5]	A[6]	A[7]	A[8]	A[9]
	2	3	8	10	16	21	35	42	43	50
③						A[5]	A[6]	A[7]	A[8]	A[9]
	2	3	8	10	16	21	35	42	43	50
②						A[5]	A[6]	A[7]	A[8]	A[9]
	2	3	8	10	16	21	35	42	43	50
③						A[5]	A[6]	A[7]		
	2	3	8	10	16	21	35	42	43	50
②						A[5]	A[6]	A[7]		
	2	3	8	10	16	21	35	42	43	50
③						A[5]	A[6]	A[7]		
	2	3	8	10	16	21	<b>35</b>	42	43	50

# Binary search: efficiency

- Binary search is very efficient: in each recursive call, the size of the problem is cut in half
  - Let the original array come with  $n$  entries; each recursive call halves the problem size:

$$n \cdot \frac{1}{2} \cdot \frac{1}{2} \cdot \frac{1}{2} \cdots$$

- Binary search is guaranteed to end after  $s$  recursive calls when the array size has been reduced to 1:

$$n \cdot \left(\frac{1}{2}\right)^s \stackrel{!}{=} 1 \quad \Leftrightarrow \quad \frac{n}{2^s} = 1 \quad \Leftrightarrow \quad s = \log_2 n$$

array size $n$	$\lceil \log_2 n \rceil$
10	4
100	7
1000	10
10000	14
100000	17
1000000	20



# MIPS: Recursive procedures

- Note that the MIPS procedure call/return via `jal a/j $ra` does *not* work for recursive procedures


- **What is going wrong?**

Using `jal` in callee *overwrites* register `$ra` which is later needed to return to caller:

```

        .text
        :
        # main program
        :
        jal proc          # invoke procedure ($ra = ★1)
★1:    :

        # procedure
proc:   :
        jal proc          # recursive call ($ra = ★2)
★2:    :

        j   $ra           #  (will jump to ★2, not ★1)

```

# MIPS: Save/restore \$ra in recursive procedure

```

        .text
        :
        # main program
        :
        jal proc          # invoke procedure ($ra = ★1)
★1:    :

        # procedure
proc:   save $ra
        :
        jal proc          # recursive call ($ra = ★2)
★2:    :
        restore $ra
        j   $ra           # will jump to ★1

```



NB: **Each invocation of `proc` needs its own place to save**

`$ra`—the save location will otherwise be overwritten in the recursive call!

# MIPS: Saving registers on the stack

- Conventionally, procedures **save registers on the stack** if they need to preserve register values
  - A **stack** is an area of memory that may grow/shrink depending on the actual space needed by a program
  - CPU register `$sp` points *just below* the last object stored on the stack
  - **Pushing** more items on the stack moves `$sp` and lets the stack grow
  - **Example** (MIPS: push 32-bit word `z` on stack):

```
subu $sp, $sp, 4
sw   z, 4($sp)
```

Address	Stack
0x7FFFFFFF	:
:	:
<code>\$sp + 8</code>	x
<code>\$sp + 4</code>	y
<code>\$sp</code> →	
:	:
0x10000000	:

before

Address	Stack
0x7FFFFFFF	:
:	:
<code>\$sp + 12</code>	x
<code>\$sp + 8</code>	y
<code>\$sp + 4</code>	z
<code>\$sp</code> →	
:	:
0x10000000	:

after

# MIPS: Saving registers on the stack

```

1      .text
2      .globl  __start
3  __start:
4      li      $a0, 1          # (0)
5      jal     proc
6  done:
7      li      $v0, 10
8      syscall
9
10     proc:
11     subu    $sp, $sp, 4
12     sw      $ra, 4($sp)    # (1), (2)
13
14     beqz    $a0, return
15     li      $a0, 0
16     jal     proc
17
18     return:
19     lw      $ra, 4($sp)
20     addu    $sp, $sp, 4    # (3), (4)
21     j       $ra
22
23     # no .data segment

```

State of stack at time  $\textcircled{t}$ :

$\textcircled{0}$

Address	Stack
0x7FFFFFFF	:
:	:
\$sp	→ ???
:	:
0x10000000	:

$\textcircled{1}$

Address	Stack
0x7FFFFFFF	:
:	:
\$sp + 4	done
\$sp	→ ???
:	:
0x10000000	:

# MIPS: Saving registers on the stack

```

1      .text
2      .globl  __start
3  __start:
4      li      $a0, 1          # (0)
5      jal     proc
6  done:
7      li      $v0, 10
8      syscall
9
10     proc:
11     subu    $sp, $sp, 4
12     sw      $ra, 4($sp)    # (1), (2)
13
14     beqz    $a0, return
15     li      $a0, 0
16     jal     proc
17
18     return:
19     lw      $ra, 4($sp)
20     addu    $sp, $sp, 4    # (3), (4)
21     j      $ra
22
23     # no .data segment

```

State of stack at time  $\textcircled{t}$ :

②

Address	Stack
0x7FFFFFFF	:
:	:
$\$sp + 8$	done
$\$sp + 4$	return
$\$sp$	→ ???
:	:
0x10000000	:

③

Address	Stack
0x7FFFFFFF	:
:	:
$\$sp + 4$	done
$\$sp$	→ return
	???
:	:
0x10000000	:

# MIPS: Saving registers on the stack

```

1      .text
2      .globl  __start
3  __start:
4      li      $a0, 1          # (0)
5      jal     proc
6  done:
7      li      $v0, 10
8      syscall
9
10     proc:
11     subu    $sp, $sp, 4
12     sw      $ra, 4($sp)    # (1), (2)
13
14     beqz    $a0, return
15     li      $a0, 0
16     jal     proc
17
18     return:
19     lw      $ra, 4($sp)
20     addu    $sp, $sp, 4    # (3), (4)
21     j      $ra
22
23     # no .data segment

```

State of stack at time  $\textcircled{t}$ :

$\textcircled{4}$

Address	Stack
0x7FFFFFFF	:
:	:
\$sp	→ done
	return
	???
:	:
0x10000000	:

- NB: the memory pointed to by \$sp and below is considered garbage

# MIPS: Recursive binary search

- **Example** (recursive binary search procedure, \$ra saved on stack):

```

1      .data
2
3 first: # sorted array of 32 bit words
4      .word  2, 3, 8, 10, 16, 21, 35, 42, 43, 50, 64, 69
5      .word  70, 77, 82, 83, 84, 90, 96, 99, 100, 105, 111, 120
6 last:  # address just after sorted array
7
8      .text
9      .globl  __start
10 __start:
11
12     # binary search in sorted array
13     #   input:  search value (needle) in $a0
14     #           base address of array in $a1
15     #           last address of array in $a2
16     #   output: address of needle in $v0 if found,
17     #           0 in $v0 otherwise
18     li      $a0, 42          # needle value
19     la      $a1, first      # address of first array entry
20     la      $a2, last - 4   # address of last array entry
21     jal     binsearch       # perform binary search
22
23     li      $v0, 10
24     syscall
25

```

# MIPS: Recursive binary search (cont.)

```

26 binsearch:
27     subu    $sp, $sp, 4           # allocate 4 bytes on stack
28     sw     $ra, 4($sp)          # save return address on stack
29
30     subu    $t0, $a2, $a1        # $t0 <- size of array
31     bnez   $t0, search          # if size > 0, continue search
32
33     move   $v0, $a1              # address of only entry in array
34     lw    $t0, ($v0)             # load the entry
35     beq   $a0, $t0, return       # equal to needle value? yes => return
36     li   $v0, 0                  # no => needle not in array
37     b    return                 # done, return
38 search:
39     sra   $t0, $t0, 3            # compute offset of middle entry m:
40     sll  $t0, $t0, 2            #   $t0 <- ($t0 / 8) * 4
41     addu $v0, $a1, $t0         # compute address of middle entry m
42     lw   $t0, ($v0)            # $t0 <- middle entry m
43     beq  $a0, $t0, return       # m = needle? yes => return
44     blt  $a0, $t0, go_left      # needle less than m? yes =>
45                                           # search continues left of m
46 go_right:
47     addu $a1, $v0, 4            # search continues right of m
48     jal  binsearch              # recursive call
49     b    return                 # done, return
50 go_left:
51     move $a2, $v0               # search continues left of m
52     jal  binsearch              # recursive call
53 return:
54     lw   $ra, 4($sp)           # recover return address from stack
55     addu $sp, $sp, 4           # release 4 bytes on stack
56
57     j    $ra                    # return to caller

```